

7202 SE International Court P.O. Box 3404 Bartlesville, OK 74006 1-800-260-9950 918-333-2000 918-333-2004 Fax

E-mail: sales@huskyportable.com

www.huskyportable.com

Self Supporting Tank Operation Manual

Thank you for choosing Husky Portable Containment for your portable tank needs. We strive to build the easiest to use, most durable and innovative products on the market today.

Husky self supporting tanks are a lightweight frameless portable water tank and require no assembly to operate. Please follow the instructions below.

- 1. Determine the location you will be setting up your tank. Make sure the area is free of sharp objects such as pointed rocks, sticks or other foreign debris.
- 2. If a ground cover is required, spread out in the chosen area for the tank and secure at the corners.
- 3. Remove your self supporting tank from the storage bag; unroll in the first direction then the other centering the tank on the ground cover.
- 4. Pull all wrinkles out of the base or floor of the tank by pulling at the base seam away from the center of the tank.
- 5. Be sure all fittings are closed or plugged.
- 6. Your self supporting tank is now ready to be filled.

Note: The tanks sides are self rising and will automatically rise with the level of the water.

Draining and Storing Your Self Supporting Tank

- 1. To drain open valve or remove plugs or caps, whichever applies.
- 2. You may push down on the side of the tank to speed up the draining process.
- 3. Once empty spread the base out.
- 4. Cover the flange using the supplied protector (piece of material) so when rolling there is no damage to your tank.
- 5. Next roll the tank from one end to the other creating a coil, start rolling at the flanged area (make sure the flange is covered and protected) from one side to the other side into a cigar shape, then roll back into the storage bag.

The material your tank is made of is mildew and rot resistant. If used with water it does not need to be 100% dry before storage.